Power System Module

Accessories

Mounting kit

for PSM busbars

Without cable routing

| For | | Model No. |
|-------|------------------------------------|-----------|
| TS | For static installation | 7856.011 |
| TS-IT | Plug and play compatibility system | 7856.029 |

With cable routing

| For | | Model No. |
|-----|--|-----------|
| | For static installation | 7856.022 |
| TS | Adjustable, for freely accessible 482.6 mm (19") level | 7856.023 |





Connection cable

for PSM-busbar

| Connection cable, 3-phase | | | |
|-------------------------------------|----------|----------|-----------|
| | Length m | Packs of | Model No. |
| CEE-conforming 5-pole/16 A | 3 | 1 pc(s). | 7856.025 |
| Connection cable, single-phase | | | |
| CEE-conforming 3-pole/16 A | 3 | 1 pc(s). | 7856.026 |
| Connection cable, UPS, single-phase | | | |
| C14/X-Com 10 A/PMC 12, 1 – 2 kVA | 3 | 1 pc(s). | 7856.027 |
| C20/X-Com 16 A/PMC 12, 3 kVA | 3 | 1 pc(s). | 7856.030 |
| Connection cable C19/C20 | | | |
| 16 A | 2 | 1 pc(s). | 7200.217 |
| Connection cable C13/C14 | | | |
| 16 A | 0.5 | 2 pc(s). | 7856.014 |





Cable lock PSM

for all modules with EN 60 320 C13 connector configurations

All terminal connection cables are therefore protected against unintentional disconnection of the power supply. Two bars are needed for two cables.

| Version | Packs of | Model No. |
|---------|-----------|-----------|
| Bar | 20 pc(s). | 7856.013 |



Accessories:

Optimum locking function is only available with connection cable 7856.014, see page 413



Overvoltage protection PSM

Connected upstream of the busbar.

- Fine fuse
- Connection:

 - Socket Wago X-COMConnector Wago X-COM

| Overvoltage protection | Packs of | Model No. |
|------------------------|-----------|------------|
| Overvoitage protection | i dono oi | Wiodel No. |
| With adaptor connector | 1 pc(s). | 7856.170 |

One overvoltage protection is required for each infeed

